

Pos.	Name / Nahme / Naziv	Code/Kode/Koda
1.1	Counter / Unterbau / boks 560 PT1	002-20001
	Counter / Unterbau / boks 660 PT1	002-20002
	Counter / Unterbau / boks 560 PT2	002-20003
	Counter / Unterbau / boks 660 PT2	002-20004
	Counter / Unterbau / boks 560 PT3	002-20005
	Counter / Unterbau / boks 660 PT3	002-20006
	Counter / Unterbau / boks 560 PT4	002-20007
	Counter / Unterbau / boks 660 PT4	002-20008
1.2	Pilar / Säule / stebriček 710 PH	002-20101
1.3	Feet / Fuß / noga 100	/
	Feet / Fuß / noga 150	/
1.4	Barrier / Barriere / pregrada PT	002-43201
2.1	Hinge holder - bottom / Scharnierhalter - untere / drzalo panta spodnji PT	002-46802
2.2	Hinge PT / Scharnier PT / tečaj PT	TC00001
2.3	Door / Tür / vrata PT	002-22001
2.4	Bush / Düse / puša	TC00008
2.5	Upper hinge / Obere Scharnier / zgornji tečajPT	002-25001
2.6	Board-holder 660 PT / Bordhalter 660 PT / nosilec police 660 PT	002-43501
	Board-holder 560 PT / Bordhalter 560 PT / nosilec police 560 PT	002-43502
2.7	Board 660 PT / Bord 660 PT / polica 660 PT	002-21101
	Board 560 PT / Bord 560 PT / polica 560 PT	002-21102
2.8	Holder-back door / Hintere Halter Tür / nosilec zadnji vrata PT	002-43101
2.9	Holder-front 735 PT / Vordere Halter 735 PT / nosilec sprednji 735 PT	002-43001
3.0	Door gasket /Türdichtung / tesnilo vrata PT	TS00023
3.1	Drawerfront 320 / Ladenfront 320 / licnica predala 320 PT	002-24002
3.2	Drawer gasket 320 / Dichtung - Ladenfront 320 / tesnilo predala PT 320	TS00026
3.3	Drawer barrier / Laden Barriere / pregrada predala PT	002-46901
3.4	Front holder 320-320 / Vordere Hlater 320-320 / nosilec sprednji 320-320 PT	002-43002
3.5	Back holder - drawers / Hintere Halter - Schublade / nosilec zadnji predali PT	002-43102
3.6	Drawer slide 550 / Führungsleiste 550 / vodilo teleskopsko 550	VOD006
3.7	Middle pillar / Zwischensäule / stebriček vmesni PT	002-20201
4.1	Drawerfront 195 / Ladenfront 195 / licnica predala 195 PT	002-24003
4.2	Drawer gasket 195 / Dichtung - Ladenfront 195 / tesnilo predala PT 195	TS00024
4.3	Front holder 195-195-195 / Vordere Halter 195-195-195 / sprednji nosilec 195-195-195 PT	002-43003
5.1	Drawerfront 460 / Ladenfront 460 / licnica predala 460 PT	002-24006
5.2	Front holder 195-460 / Vordere Hlater 195-460 / nosilec sprednji 195-460 PT	002-43006
5.3	Drawer gasket 460 / Dichtung - Ladenfront 460 / tesnilo predala 460 PT	TS00028
6.1	Drawerfront 370 / Ladenfront 370 / licnica predala 370 PT	002-24005
6.2	Drawerfront 270 / Ladenfront 270 / licnica predala 270 PT	002-24004
6.3	Drawer gasket 270 / Dichtung - Ladenfront 270 / tesnilo predala 270 PT	TS00025
6.4	Front holder 270-370 / Vordere Halter 270-370 / nosilec sprednji 270-370 PT	002-43004
6.5	Drawer gasket 370 / Dichtung - Ladenfront 370 / tesnilo predala PT 370	TS00027
7.1	Front-holder 370-270 / Vordere Hlater 370-270 / nosilec sprednji 370-270 PT	002-43005
8.1	Main switch SS / CNS Hauptschalter / stikalo inox on-off	ELM0049
8.2	Digital Thermostat / Digital Regler / regulator EVCO	ELM0019
8.3	SS Mask PT-RU / CNS Schalterblende PT-RU / maska PT-RU	002-49001
8.4	I-compartment 660 PT-RU /Installationsfach 660 PT-RU / ohišje agregata 660 PT-RU	002-26201
	I-compartment 560 PT-RU /Installationsfach 560 PT-RU / ohišje agregata 560 PT-RU	002-26205
8.5	Perforated mask / Perforiere Blende / rešetka PT	002-49102

8.6	Antidust foam filter PH-260 / Anti-Staub-Filterschaum PH-260 / filter prašni PH-260_pena	001-26250
	Antidust SS filter PH-260 / Anti-Staub CNS Filter PH-260 / filter PH-260 inox	001-26301
8.7	SS Mask PT / CNS Schalterblende PT / maska PT	002-49002
8.8	I-compartment 660 PT / Installationsfach 660 PT / ohišje agregata 660 PT	002-26202
	I-compartment 560 PT / Installationsfach 560 PT / ohišje agregata 560 PT	002-26206
9.1	Revision-Evaporator PT / Revision-Verdampfer PT / revizija uparjalnika PT	002-48501
9.2	Radial fan / Radial Motor / ventilator EBM	ELM0030
9.3	Evaporator AL-CU big / Verdampfer AL-Cu groß / uparjalnik Al-Cu veliki	HLO0004
9.4	Evaporator housing / Verdampfer Gehäuse / plašč uparjalnika PT	002-48202
9.5	Probe PTC 3m / Sonde PTC 3m / tipalo 3m	ELM0020
9.6	Evaporator PT1 / Verdampfer PT1 / uparjalnik PT1	HLO0005
9.7	Evaporator housing PT1 / Verdampfer Gehäuse PT1 / plašč uparjalnika PT1	002-48201
9.8	Radial fan EBM 4656 N / Radial Motor EBM 4656 N / ventilator EBM 4656 N	ELM0106
10.1	Solenoid valve / Magnetventil / elektromagnetni ventil	HLO0020
10.2	Expansion valve / Ekspansionsventil / ekspanzijski ventil R134a/R513A	HLO0025
	Expansion valve / Ekspansionsventil / ekspanzijski ventil R404a/R452a	HLO0026
	Expansion valve / Ekspansionsventil / ekspanzijski ventil R448a/R449a	HLO0027
10.3	Dose / Dosis / doza 100x100x50	ELM0058
10.4	Dose holder / Dosen Hlater / držalo doze PT	002-49401
10.5	Drain pipe / Ablauf Rohr / odtočna cev fi12	/
10.6	Filling valve / Füller / polnilni ventil	HLO0019
11.1	Condenser protection / Kondensatorschutz / zaščita kondenzatorja 73	002-48101
11.2	Condenser 73 / Kondensator 73 / kondenzator 73	HLO0006
11.3	Compressor / Kompressor / kompresor EMT6144Z R134a	HLO0008
	Compressor / Kompressor / kompresor EMT6160Z R134a	HLO0009
	Compressor / Kompressor / kompresor NEK6187Z R134a	HLO0010
	Compressor / Kompressor / kompresor EMT6144U R290	HLO0011
	Compressor / Kompressor / kompresor EMT6165U R290	HLO0012
	Compressor / Kompressor / kompresor NEU2140U R290	HLO0013
	Compressor / Kompressor / kompresor NEU2155U R290	HLO0014
	Compressor / Kompressor / kompresor NT2170U R290	HLO0015
	Compressor / Kompressor / kompresor T2180U R290	HLO0016
11.4	Drain tray / Ablauf Tasse / odtočna posoda uparjalnika PT	002-48601
11.5	Baseplate / Grundplatte / podloga PT	002-48001